

# RIFF JTAG Error codes and troubleshooting

## Error code 0x27

### 2.7. Error code 0x27

Returned by the DCC Loader when it fails waiting for selected flash memory controller to assert ready status.

#### **Explanation:**

May happen if target is currently in some unrecoverable h/w state or if memory controller is not properly initialized or due to some other reasons. Shall not happen since it is DCC Loader's task to initialize and communicate with memory controller properly. Can happen if target has a damaged memory chip.

Unique solution ID: #1032

Author: Legija

Last update: 2012-04-28 13:22