RIFF JTAG Error codes and troubleshooting

ERROR: Read/Write memory failed during H/W Init

ERROR: Read/Write memory failed during H/W Init

This error can happen due to few reasons:

- NRST or GND pins not connected properly
- Wrong model selected
- Hardware failure

Solution:

Connect NRST and GND pins properly. In case that You're trying to access officially unsupported device, contact support for correct H/W Initi settings.

Unique solution ID: #1039
Author: Legija
Last update: 2012-04-28 13:58

(c) 2026 Legija <> | 2026-11-23 23:32
URL: https://faq.riffbox.org/content/4/40/en/error-read_write-memory-failed-during-h_w-init.html