

# **RIFF JTAG Error codes and troubleshooting**

## **Error code 0x31**

### **2.7. Error code 0x31**

Returned by the DCC Loader when it fails to program part of flash memory due to unrecognized (by the DCC Loader) reasons.

Unique solution ID: #1029

Author: Legija

Last update: 2012-04-28 13:19