

RIFF JTAG Error codes and troubleshooting

Error code 0x31

2.7. Error code 0x31

Returned by the DCC Loader when it fails to program part of flash memory due to unrecognized (by the DCC Loader) reasons.

Unique solution ID: #1029

Author: Legija

Last update: 2012-04-28 13:19