

# RIFF JTAG Error codes and troubleshooting


## ERROR: Main data file size is less than requested to flash to main

### ERROR: Main data file size is less than requested to flash to main

Happens when "Autofullflash size" is used and file selected in main field is less than detected flash chip size.

Solution:

Use "File Size" option in Data Length field instead of auto fullflash size.



Unique solution ID: #1040

Author: Legija

Last update: 2012-04-28 14:18