

# RIFF JTAG Error codes and troubleshooting


## ERROR: Main data file size is less than requested to flash to main

**ERROR: Main data file size is less than requested to flash to main**

Happens when "Autofullflash size" is used and file selected in main field is less then detected flash chip size.

Solution:

Use "File Size" option in Data Length field instead of auto fullflash size.



Unique solution ID: #1040

Author: Legija

Last update: 2012-04-28 14:18