

# RIFF JTAG Error codes and troubleshooting

## WARNING: DCC Loader was unable to initialize FLASH1 chip.

WARNING: DCC Loader was unable to initialize FLASH1 chip. Error code: 0x00000000

This error is returned by DCC loader in case that memory chip is not detected. Usually it happens when chip itself is dead, or it's not powered.

User should replace memory chip, or in rare cases check power supply circuitry.

Unique solution ID: #1053

Author: Legija

Last update: 2012-05-03 18:31