RIFF JTAG Error codes and troubleshooting

Error code 0x2E

2.6. Error code 0x2E

Returned by the DCC Loader when it fails to erase flash memory’s logical block and cannot determine the reason of such error.

Solution:

Ask developer for smarter DCC loader ! 

Unique solution ID: #1025
Author: Legija
Last update: 2012-04-28 13:14

(c) 2026 Legija <> | 2026-11-24 19:27
URL: https://faq.riffbox.org/content/4/26/en/error-code-0x2e.html